Size:61.75 x 156.75mm

GL301

GP Portable PowerBank

Instruction Manual

Micro USB Input (Input/Output)

Portable PowerBank

USB Output (Output/Input)

Bonjourno

Type-C Connector | Micro USB Connector | Apple Connector | Micro USB Connector | Type-C Connector

Specification

Input	5V DC 1000mA
Output	5V DC 2.1A and 5V DC 1A
Dimension	110(L)x77(W)x24(H)mm
Weight (Power Pack only)	240g
Operating Temperature	0°C ~ 40°C
Battery Pack(s)	Li-ion battery 3.7V 10000mAh
Charging Time	5V / adapter (2A output) 10.2 hours (approx.)

The above charging time may vary under different operating conditions.

Charging and discharging of the Power Pack

Before charging, the LED displays its its normal state of the Portable PowerBank will light up.

Testing battery status:

Battery Strength	LED Indicator	Remarks
Good	Four LED on	No need for recharging
Good to average	Three LED on	-
Average	Two LED on	-
weak	One LED on	-
Very Weak	LED blinking	Need to be recharged
No power	No LED	Need to be recharged immediately

Cover

High Capacity Power Pack Features

- Compact and lightweight design, easy to carry
- Convenient to recharge by USB adaptor
- LED indicators to show battery level
- Overcharge protection
- Over temperature protection
- Over voltage/ under voltage protection
- Short circuit protection
- Over power protection

Read the instruction manual thoroughly before use. Keep the manual for future reference.

Operating Instructions

Charging your Portable Power Pack

1. Plug the micro USB connector into the charging adaptor/ data line the input port of the Portable PowerBank. Connect another end of the USB charging adaptor/ data line into the USB port of the PC or the USB charger.
2. Micro USB will be on with power connection. Four LED will indicate the battery status. The number of LED lights up indicates the battery level.
3. Four LED lights up means the battery is full.
4. Disconnect the USB when after charging is complete.

Charging other electronic devices

1. Plug the USB cable into the USB output port of the fully charged Portable PowerBank, then connect another end of the USB cable to your electronic device. Four LED will light up. The USB charging cable supplied with your Portable PowerBank is optional.
2. Dual USB output ports are designed for charging two of electronic devices simultaneously.
3. The electronic devices will be instantly charged, and it can be used while charging is in progress.
4. Use the charging cable of electronic device to check the charging status.
5. When charging is completed, unplug the USB charging cable from the electronic device and the Portable PowerBank. The Portable PowerBank will switch to standby mode.

6. To extend its lifetime, please fully charge the Portable PowerBank. The LED indicator will show the strength of the battery.

Attention

1. It is normal for the casing to become warm during charging and it will provide a safe and reliable charging process.
2. Please recharge the Portable PowerBank before use if it has not been used more than 90 days.
3. Do not use the Portable PowerBank in place with high humidity, high temperature or extreme conditions.

Caution

1. Do not use, immerse or disassemble the Portable PowerBank and its other accessories.
2. Do not throw, disassemble, open, drop, crush, puncture or shred the internal battery.
3. Avoid away from open flame or any heat source to prevent overheating.
4. Keep away from high voltage devices.
5. Keep away from children and pets.
6. This appliance is not intended for use by young children or infirm persons unless they have been adequately supervised by a responsible person to ensure that they can use the appliance safely. Young children should be supervised to ensure that they do not play with the appliance.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning!

Cancer and reproductive harm - www.P65warnings.ca.gov

Cleaning and Storage

- Clean with a dry cloth. Do not use any cleaning solvents, chemicals, or other abrasive substances that may damage the finish of the product. Do not immerse in water. Do not fix the product on a hot surface, dangerous chemicals and corrosive environment. Do not fix the product on a hot surface, dangerous chemicals and corrosive environment.

Read the instruction manual thoroughly before use. Keep the manual for future reference.

Operating Instructions

Charging your Portable Power Pack

1. Plug the micro USB connector into the charging adaptor/ data line the input port of the Portable PowerBank. Connect another end of the USB charging adaptor/ data line into the USB port of the PC or the USB charger.
2. Micro USB will be on with power connection. Four LED will indicate the battery status. The number of LED lights up indicates the battery level.
3. Four LED lights up means the battery is full.
4. Disconnect the USB when after charging is complete.

Charging other electronic devices

1. Plug the USB cable into the USB output port of the fully charged Portable PowerBank, then connect another end of the USB cable to your electronic device. Four LED will light up. The USB charging cable supplied with your Portable PowerBank is optional.
2. Dual USB output ports are designed for charging two of electronic devices simultaneously.
3. The electronic devices will be instantly charged, and it can be used while charging is in progress.
4. Use the charging cable of electronic device to check the charging status.
5. When charging is completed, unplug the USB charging cable from the electronic device and the Portable PowerBank. The Portable PowerBank will switch to standby mode.
6. To extend its lifetime, please fully charge the Portable PowerBank. The LED indicator will show the strength of the battery.

Attention

1. It is normal for the casing to become warm during charging and it will provide a safe and reliable charging process.
2. Please recharge the Portable PowerBank before use if it has not been used more than 90 days.
3. Do not use the Portable PowerBank in place with high humidity, high temperature or extreme conditions.

Caution

1. Do not use, immerse or disassemble the Portable PowerBank and its other accessories.
2. Do not throw, disassemble, open, drop, crush, puncture or shred the internal battery.
3. Avoid away from open flame or any heat source to prevent overheating.
4. Keep away from high voltage devices.
5. Keep away from children and pets.
6. This appliance is not intended for use by young children or infirm persons unless they have been adequately supervised by a responsible person to ensure that they can use the appliance safely. Young children should be supervised to ensure that they do not play with the appliance.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning!

Cancer and reproductive harm - www.P65warnings.ca.gov

Cleaning and Storage

- Clean with a dry cloth. Do not use any cleaning solvents, chemicals, or other abrasive substances that may damage the finish of the product. Do not immerse in water. Do not fix the product on a hot surface, dangerous chemicals and corrosive environment. Do not fix the product on a hot surface, dangerous chemicals and corrosive environment.

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30

LV

Lietus jaudas Power Pack īpašības

- Lietas jaudas Power Pack ar Wip jonu 10400mAh baterijām ieslēdz baterijas
- ieslēdz ar divkāršu barošanu, kamēr to lādē datorā/ucmu.
- LED ādiņš, izmantojot LED ādiņošanu
- Lādēšana ar USB adaptera/ datu kabeli
- Izlādējuma mērīšana
- - atverot ierīces ādiņu pusē ieslēdzas ādiņošanas ierīce
- - ādiņošanas ierīce darbojas 10 sekundes
- - izlādējuma ādiņošanas ierīce
- - jālāde baterijas ādiņošanas ierīce

Pirms ierīces lietošanas rūpīgi izlasiet lietotāja pamācību. Saglabājiet lietotāja pamācību.

Darba instrukcijas

Lādēja jaudas Power Pack izmantošana

1. Iespraudiet mikro USB savienojumu mikro USB ievietnē, Portable PowerBank ievietes portā. Otrs USB izlādes kabeļa galu pievienojiet datorplatas ievietes portā, izmantojot 5 kontakta USB ieejas/izejas savienojumu.
2. Ieslēdzas kabeļ daļa darbojas mikro USB indikācijas LED kabelim ieslēdzas ieslēdzas, ieslēdzas LED ādiņošanas ādiņošanas ādiņošanas