

SHARP


MODEL

XL-HF202PH(S) XL-HF202PH(BK) XL-HF202PH(TK)

HI FI COMPONENT SYSTEM

OPERATION MANUAL

Thank you for purchasing this SHARP product. To obtain the best performance from this product, please read this manual carefully. It will guide you in operating your SHARP product.




The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by SHARP is under license. Other trademarks and trade names are those of their respective owners.

Special Note
Supply of this product does not carry a license nor imply any right to distribute content created with this product in revenue-generating broadcast systems (terrestrial, satellite, cable and/or other distribution channels), revenue-generating streaming applications (via Internet, intranets and/or other networks), other revenue-generating content distribution systems (pay-audio or auto-on-demand applications and the like) or on revenue-generating physical media (compact discs, digital versatile discs, semiconductor chips, hard drives, memory cards and the like). An independent license for such use is required. For details, please visit <http://mp3licensing.com>

MPEG Layer-3 audio coding technology licensed from Fraunhofer IIS and Thomson.

System connections

Make sure to unplug the AC power lead before making any connections.
To select Line in function: Press the FUNCTION button (main unit) or AUDIO/LINE (INPUT) button (remote control) repeatedly until Line in is displayed.



- Aerial connection**
Connect the FM 75 OHMS socket and position it where reception is best.
- Speaker connection**
Use speakers with an impedance of 4 ohms or more, as lower impedance speakers can damage the unit.
- Demonstration mode**
The first time the unit is plugged in, it will enter the Bluetooth stand-by (demonstration) mode.
- Auto power off function**
The main unit will enter the stand-by mode when iPad, iPod or iPhone is not connected after 15 minutes of inactivity during:
- Volume auto fade-in**
If you turn off and on the main unit with the volume set to 27 or higher, the volume starts at 16 and fades in to the last level.
- Volume control**
Turn the volume knob towards VOL+/- (main unit) or press VOL +/- (remote control) to increase or decrease the volume.
- Muting**
To mute the volume, press the M button (remote control). Press again to restore the volume.
- Direct key power on function**
When you press any of the following buttons, the unit turns on:
- Function**
Press the FUNCTION button repeatedly to select desired function.

Listening to Bluetooth enabled devices (continued)

- Pairing with other Bluetooth source devices**
1. Press the ON/STAND-BY button to turn the power on.
- Listening to the sound**
1. Press the ON/STAND-BY button to turn the power on.
- To disconnect the Bluetooth device**
1. Disconnect the Bluetooth connection on the audio source device.
- Auto power on**
During Bluetooth Stand-by mode, when music is played from your device, the unit will automatically power on when the Bluetooth connection has been set up between the main unit and your device and they remain connected.

Listening to a CD or MP3/WMA disc (continued)


- Repeat play**
Repeat play can play one track, all tracks of a programmed sequence continuously.
- Programmed play (CD)**
1. While in the stop mode, press the MEMORY button on the remote control to enter the programming save mode.
- Programmed play (MP3/WMA)**
1. While in the stop mode, press the MEMORY button on the remote control to enter the programming save mode.
- Random play**
To random play all tracks: Press the MEMORY button on the remote control until "Random" appears.

Listening to USB mass storage device/MP3 player

- To play back USB/MP3 player with folder mode on**
1. Press the USB button (remote control) or FUNCTION button (main unit) repeatedly to select USB function.
- To remove USB memory device**
1. Press the (CD/USB) button to stop playback.

Special Notes

- Warnings**
When the ON/STAND-BY button is set at STAND-BY position, mains voltage is still present inside the unit.
- Accessories**
The following accessories are included:
- Remote control x 1
- Speaker wires x 2
- FM aerial x 1
- Velcro tape (hook type) x 2
- Velcro tape (loop type) x 3



The illustration printed in this operation manual are for model XL-HF202PH(S).

Front panel

- Remote sensor
- Timer Indicator
- Docking Station for iPod or iPhone
- Pairing Button
- Volume Control
- FUNCTION Button
- On/Stand-by Button
- USB Terminal
- Auto In Socket
- Headphone Socket
- Tuner Preset Down, CD/USB, iPod/iPhone Skip Down Button
- Tuner Preset Up, CD/USB, iPod/iPhone Skip Up Button
- Disc/USB Stop Button
- Disc/USB/MP3/Phone Play or Pause Button
- Disc Tray Open/Close Button

Bluetooth one touch connection via NFC

- About NFC technology**
Near Field Communication (NFC) is a set of standards for devices (smartphones/tablets) to establish radio communication with each other by touching/tapping them together or bringing them into close proximity.
- NFC tag set up**
The NFC tags can be placed anywhere convenient to you. The velcro tapes supplied will help to secure the tags onto the desired location.
- Bluetooth one touch connection via NFC**
1. Peel the separator off the velcro tape (loop type) and stick it on a desired surface.
- Bluetooth one touch connection via NFC (continued)**
1. NFC connection for audio playback
2. Bluetooth operation buttons (remote control only)

Listening to the iPod, iPhone or iPad (continued)

- Pairing with other Bluetooth source devices**
1. Press the ON/STAND-BY button to turn the power on.
- Listening to the sound**
1. Press the ON/STAND-BY button to turn the power on.
- To disconnect the Bluetooth device**
1. Disconnect the Bluetooth connection on the audio source device.
- Auto power on**
During Bluetooth Stand-by mode, when music is played from your device, the unit will automatically power on when the Bluetooth connection has been set up between the main unit and your device and they remain connected.

Listening to a CD or MP3/WMA disc (continued)

- Repeat play**
Repeat play can play one track, all tracks of a programmed sequence continuously.
- Programmed play (CD)**
1. While in the stop mode, press the MEMORY button on the remote control to enter the programming save mode.
- Programmed play (MP3/WMA)**
1. While in the stop mode, press the MEMORY button on the remote control to enter the programming save mode.
- Random play**
To random play all tracks: Press the MEMORY button on the remote control until "Random" appears.

Listening to USB mass storage device/MP3 player

- To play back USB/MP3 player with folder mode on**
1. Press the USB button (remote control) or FUNCTION button (main unit) repeatedly to select USB function.
- To remove USB memory device**
1. Press the (CD/USB) button to stop playback.


Listening to the iPod, iPhone or iPad (continued)

- Pairing with other Bluetooth source devices**
1. Press the ON/STAND-BY button to turn the power on.
- Listening to the sound**
1. Press the ON/STAND-BY button to turn the power on.
- To disconnect the Bluetooth device**
1. Disconnect the Bluetooth connection on the audio source device.
- Auto power on**
During Bluetooth Stand-by mode, when music is played from your device, the unit will automatically power on when the Bluetooth connection has been set up between the main unit and your device and they remain connected.

Precautions

- General**
1. Do not place anything on top of the unit.
2. Do not touch the front panel or any other part of the unit while the unit is powered on.
- Speaker system**
1. Do not place anything on top of the unit.
2. Do not touch the front panel or any other part of the unit while the unit is powered on.

Controls and indicators



Bluetooth one touch connection via NFC (continued)

- Bluetooth one touch connection via NFC**
1. NFC connection for audio playback
2. Bluetooth operation buttons (remote control only)
- Bluetooth one touch connection via NFC (continued)**
1. NFC connection for audio playback
2. Bluetooth operation buttons (remote control only)

Listening to the iPod, iPhone or iPad (continued)

- Pairing with other Bluetooth source devices**
1. Press the ON/STAND-BY button to turn the power on.
- Listening to the sound**
1. Press the ON/STAND-BY button to turn the power on.
- To disconnect the Bluetooth device**
1. Disconnect the Bluetooth connection on the audio source device.
- Auto power on**
During Bluetooth Stand-by mode, when music is played from your device, the unit will automatically power on when the Bluetooth connection has been set up between the main unit and your device and they remain connected.

Listening to a CD or MP3/WMA disc (continued)

- Repeat play**
Repeat play can play one track, all tracks of a programmed sequence continuously.
- Programmed play (CD)**
1. While in the stop mode, press the MEMORY button on the remote control to enter the programming save mode.
- Programmed play (MP3/WMA)**
1. While in the stop mode, press the MEMORY button on the remote control to enter the programming save mode.
- Random play**
To random play all tracks: Press the MEMORY button on the remote control until "Random" appears.


Listening to USB mass storage device/MP3 player

- To play back USB/MP3 player with folder mode on**
1. Press the USB button (remote control) or FUNCTION button (main unit) repeatedly to select USB function.
- To remove USB memory device**
1. Press the (CD/USB) button to stop playback.

Listening to the iPod, iPhone or iPad (continued)

- Pairing with other Bluetooth source devices**
1. Press the ON/STAND-BY button to turn the power on.
- Listening to the sound**
1. Press the ON/STAND-BY button to turn the power on.
- To disconnect the Bluetooth device**
1. Disconnect the Bluetooth connection on the audio source device.
- Auto power on**
During Bluetooth Stand-by mode, when music is played from your device, the unit will automatically power on when the Bluetooth connection has been set up between the main unit and your device and they remain connected.

Controls and indicators (continued)



Bluetooth one touch connection via NFC (continued)

- Bluetooth one touch connection via NFC**
1. NFC connection for audio playback
2. Bluetooth operation buttons (remote control only)
- Bluetooth one touch connection via NFC (continued)**
1. NFC connection for audio playback
2. Bluetooth operation buttons (remote control only)

Listening to the iPod, iPhone or iPad (continued)

- Pairing with other Bluetooth source devices**
1. Press the ON/STAND-BY button to turn the power on.
- Listening to the sound**
1. Press the ON/STAND-BY button to turn the power on.
- To disconnect the Bluetooth device**
1. Disconnect the Bluetooth connection on the audio source device.
- Auto power on**
During Bluetooth Stand-by mode, when music is played from your device, the unit will automatically power on when the Bluetooth connection has been set up between the main unit and your device and they remain connected.

Listening to a CD or MP3/WMA disc (continued)

- Repeat play**
Repeat play can play one track, all tracks of a programmed sequence continuously.
- Programmed play (CD)**
1. While in the stop mode, press the MEMORY button on the remote control to enter the programming save mode.
- Programmed play (MP3/WMA)**
1. While in the stop mode, press the MEMORY button on the remote control to enter the programming save mode.
- Random play**
To random play all tracks: Press the MEMORY button on the remote control until "Random" appears.

Listening to USB mass storage device/MP3 player

- To play back USB/MP3 player with folder mode on**
1. Press the USB button (remote control) or FUNCTION button (main unit) repeatedly to select USB function.
- To remove USB memory device**
1. Press the (CD/USB) button to stop playback.

Listening to the iPod, iPhone or iPad (continued)

- Pairing with other Bluetooth source devices**
1. Press the ON/STAND-BY button to turn the power on.
- Listening to the sound**
1. Press the ON/STAND-BY button to turn the power on.
- To disconnect the Bluetooth device**
1. Disconnect the Bluetooth connection on the audio source device.
- Auto power on**
During Bluetooth Stand-by mode, when music is played from your device, the unit will automatically power on when the Bluetooth connection has been set up between the main unit and your device and they remain connected.

