

SONY®




SRS-XB31

4-734-038-13(1)



©2018 Sony Corporation Printed in China




* 4 7 3 4 0 3 8 1 3 * (1)




1




2




3












ON



OFF



Android



Android / iPhone



<http://www.sony.net/smcapp/>



Wireless Party Chain
Speaker Add
Party Booster



http://rd1.sony.net/help/speaker/srs-xb31/h_zz/