

CAMANGI

FM600

Quick Start Guide



Table of Contents

What's in the Box?	1
Your Device.....	2
Installing SIM Card and Memory Card	3
Charging Battery	3
Data connection	4
First Start Up	6
Home Screen	6
Making Your First Call.....	7
Entering Information.....	8
Contacts	9
Sending a Text Message	10
Sending a Multimedia Message	10
Sending a Voice MMS.....	11
Setting up Wi-Fi.....	12
Setting up Email Account	13
Sending and Receiving Emails	14
Using Browser.....	15


Table of Contents

Using Bluetooth.....	16
Taking Photos and Videos	17
Viewing Photos and Videos	18
Using Aldiko	19
Changing Basic Phone Settings.....	20

Congratulations on your purchase of this smartphone device. **Quick Start Guide** will help you go through the basic features of your device.

What's in the Box?

Your package comes with the following items. If any of them is missing, please contact your retailer.



Device



Mini USB cable



Pouch



AC Adapter







Quick Start Guide



Headset

Your Device




Installing SIM Card and Memory Card

To install SIM card and microSD card

1. Open the card cover.
2. Insert SIM/microSD card with the gold contacts facing up as shown on the illustration.
3. Close the card cover.

NOTE:

- To remove the memory card, push it down to eject it from the slot.
- Do not remove the memory card while the device is turned on. Sudden removal of the memory card may cause data loss or unpredictable system hang up.




Charging Battery

1. Connect one end of the AC adapter to mini USB connector of the device.
2. Plug the other end of the AC adapter to the wall outlet to start charging.


NOTE:

- Charging time with in-box 5V/2A AC adapter, less than 3 hours (power-off mode). Battery life may vary depending on user usage.
- Battery can also be charged when device connects to computer through USB cable.





Data connection

1. Connect FM600's USB mini-B to your PC's USB adaptor.
2. Gently press the status bar and slightly scroll down. You can see the options for USB connected from Notification.




3. Press USB connected, select "Turn on USB storage" and press "ok" for few seconds.





4. You can see the new hard drive  at “My Computer”. You can put your files in the hard drive now.
5. Please press status bar and scroll down after the connection is done.




First Start Up

After installing SIM card and charging battery, device is ready to turn on.

Home Screen

From Home screen, you can quickly access common features, view notifications of missed calls, received messages and check connection status.




Tap **Application Drawer**  to access applications and settings of the device.

Making Your First Call

On Home screen, tap  > **Phone**.

To make a voice call

1. Tap phone number on keypad.
2. Tap  to erase a wrong number. Tap and hold  to erase entire number.
 **NOTE:** To call a contact, tap the contact from the list.
3. After entering phone number, tap .
4. To end the call, tap .



To answer a call

To answer a call, tap .

Entering Information

Regardless of the application, you can enter information using on-screen keyboard.

To use on-screen keyboard


When an application requires text input, tap the input box to display on-screen keyboard.

1. Tap the input box to display on-screen keyboard.

 **NOTE:** To toggle between capital and small letter display, tap . To display numeric and symbols keyboard, tap . Tap  to toggle back.

2. Tap keys on the keyboard to enter characters.

 **NOTE:** If word completion is activated, the screen displays a list of suggested words as typing the characters.




Contacts

To add a Contact

1. On Home screen, tap **Contacts**.
2. Tap **Menu > New contact**.
3. Enter contact information such as name, phone number, email address etc. Tap **Done** to save the contact or tap **Revert** to exit without saving any change.

 **NOTE:** SIM Contact only stores name and phone number. To store more information such as an email address, create a new contact on the device.




To import contacts

1. On Home screen, tap **Contacts**.
2. Tap **Menu > Import/Export**.
3. Select to import contacts from **SIM Card** or **SD Card**.
4. Select contacts to import or tap **Menu** to select **Import all**.

Sending a Text Message

1. On Home screen, tap **Messaging**.
2. Tap **New message**.
3. In **To** field, enter the recipient's phone number, then tap **Next**.
4. Type message in the **Type to compose** field, then tap **Done**.
5. Tap **Send**.




Sending a Multimedia Message

A multimedia message (MMS) can contain graphic and audio files.

1. On Home screen, tap **Messaging**.
2. Tap **New message** > **Menu** > **Add subject**.
The message automatically converts to an MMS message.
3. Enter mobile phone number or email address of the recipient in the **To** field then type the **Subject**.
4. To add components, tap **Menu** > **Attach** to attach pictures or videos.
5. Tap **Send**.

Sending a Voice MMS

1. On Home screen, tap **Messaging**.
2. Tap **New Message** > **Menu** > **Attach** > **Record audio**.
3. Tap  to start recording.
4. Tap  to stop recording.
 **NOTE:** Tap  to play the voice. Tap **Use this recording** to store the voice. Tap **Discard** to delete the voice. After storing the voice, you can also tap to **Play**, **Replace** and **Remove** the voice.
5. Enter the mobile phone number in the **To** field. The voice message can be sent up to 20 recipients.
6. Tap to enter message in the box and tap **Send**.



Setting up Wi-Fi


Connect to a wireless network to browse Internet.

1. On Home screen, tap  > **Settings**.
2. Tap **Wireless & networks**.
3. Tap **Wi-Fi** to activate.
4. Tap **Wi-Fi settings** > **Network notification** to start detecting networks. The available networks will then be listed.
5. Tap **Add Wi-Fi network** to add a connection.

 **NOTE:** Connecting to a secured network will prompt for password. Enter password then tap **Connect**.

Setting up Email Account


1. On Home screen, tap  > **Email**.
2. Select your email account provider.
3. Enter your **Email address** and **Password**.
4. Tap **Next**. The device will automatically retrieve email settings.
5. Enter **Name** and **Account display name**.
6. Tap **Done**.



Sending and Receiving Emails

Composing and sending emails

1. On Home screen, tap  > **Email**, then tap an email account.
2. Tap **Menu** > **Compose**.
3. In **To** field, enter recipient's email address.
4. Enter **Subject**.
5. Compose contents.
6. Tap **Send**.



Adding attachments to an email message

1. Tap **Menu** > **Add attachment**.
2. Select items to attach.

Receiving emails

Emails are automatically received in Inbox folder when phone connects to network.

1. On Home screen, tap  > **Email**, then tap an email account.
2. Tap **Menu** > **Refresh**.

Using Browser

To open a web page

1. On Home screen, tap  > **Browser**.
 2. Tap the address bar.
 3. Type the URL then tap .
- Tap **Menu** to access more functions.




Swipe your finger up or down to scroll the page.

Quick search on the web


From the Home screen, you can search information on the web with **Google Search**.

1. Tap **Google Search** widget.
2. Type text to search in the Quick Search Box.
3. Tap .



Using Bluetooth

1. On Home screen, tap  > **Settings**.
2. Tap **Wireless & networks**.
3. Tap **Bluetooth** to activate.
4. To search for a new device, tap **Bluetooth settings** > **Scan for devices**.
5. Tap the detected device to connect.
6. Enter the **PIN** to start pairing, then tap **OK**.
 **NOTE:** PIN of the device must be the same PIN on the other pairing bluetooth headsets.
7. The paired bluetooth headset name is displayed.
8. Tap **Done**.




Taking Photos and Videos

This device is equipped with a 3.0 megapixels camera to take photos and videos.


To take a photo

1. On Home screen, tap  > **Camera**.
2. Aim the device at the subject, then tap and hold  to focus.
3. The focus frame turns green to indicate focus is set, tap  to take the shot.



To record video


1. On Home screen, tap  > **Camcorder**.
 2. Aim the device at the subject.
 3. Tap  to start recording.
 4. Tap  again to stop.
-  **NOTE:** When in camcorder or camera mode, tap **Menu** > **Settings** to adjust camcorder or camera settings.



Viewing Photos and Videos

To view photos

1. On Home screen, tap  > **Gallery** > **Camera pictures**.
2. Tap an image to view.
3. To view previous/next image, tap left/right of the screen.
4. To play slideshow, tap **Menu** > **Slideshow**.
5. To share or edit an image, tap **Menu** to show options.



To play back videos

1. On Home screen, tap  > **Videos**.
2. Tap the video to play. Tap  to rewind/pause/fast forward the video clip.



Using Aldiko

The Aldiko program allows you to download ebooks from online catalog for viewing on your smartphone.


To browse an ebook

1. On Home screen, tap  > **Aldiko**.
2. Select an ebook from your bookshelf and tap to open the book.
3. Swipe your fingers right and left to flip to the previous and the next page.

To download an ebook

1. On Home screen, tap  > **Aldiko** > **Download books**.
2. Select from a list of publishers from Aldiko Online Catalog.
3. Tap on the book you want to download and tap **Download**.
4. The downloaded book appears on your bookshelf.

 **NOTE:** You may need to pay for downloading ebooks.




Changing Basic Phone Settings

To change the ringtone

1. On Home screen, tap  > **Settings** > **Sound** > **Phone ringtone**.
2. Select preferred ringtones from the list.
3. Tap **OK** to confirm.

To set the alarm

1. On Home screen, tap  > **Clock**.
2. Tap a checkbox to activate an alarm or tap an alarm to enter set alarm submenu.
3. In set alarm submenu, tap an option to change.
4. Tap **Label** to enter alarm description.
5. Tap the checkbox of **Turn on alarm** to activate.



Please read before proceeding

SAFETY INFORMATION

- Use only the batteries and power adapter provided by the manufacturer. The use of unauthorized accessories may void your warranty.
- Do not store your phone in temperatures higher than 50°C or 122°F.

SAFETY PRECAUTIONS FOR BATTERY USE

- Use only an approved battery.
- Keep the battery dry and away from any liquid since this may cause a short circuit.
- If the battery emits a foul odor, discontinue use.
- If the battery leaks:
 - Do not allow the leaking fluid to come in contact with your skin, eyes or clothing. If already in contact, rinse with clean water immediately and seek medical advice.
 - Keep the battery away from fire since this may cause the battery to explode.
- Do not attempt to open or service the battery yourself.
- Do not dispose battery in fire or water.
- Recycle or dispose used batteries according to the local regulations.

ROAD AND ENVIRONMENTAL SAFETY

- Turn off the phone in areas with a potentially explosive atmosphere or where flammable objects exist such as gas stations, fuel depots, and chemical plants among others. Sparks from these areas could cause explosion or fire and result in injury or even death.
- Do not use hand-held phones while driving a vehicle. Use hands-free devices as an alternative.

SAFETY IN AIRCRAFT

Do not use the phone on board an aircraft. The phone's network signals may cause interference to the navigation system. As a safety measurement, it is against the law in most countries to use the phone on board an aircraft.

Copyright © 2010. All Rights Reserved.

Android is a trademark of Google Inc. Use of this trademark is subject to Google Permissions.

This product has an Android™ platform based on Linux, which can be expanded by a variety of JME-based application SW.

All products use in this device and trademarks mentioned herein are trademarks or registered trademarks of their respective owners.

Google™, the Google logo, Android™, the Android logo and Gmail™ are trademarks of Google Inc. Use of this trademark is subject to Google Permissions.

Wi-Fi and the Wi-Fi CERTIFIED logo are registered trademarks of the Wireless Fidelity Alliance.

microSD™ is a trademark of SD Card Association.

Bluetooth and the Bluetooth logo are trademarks owned by Bluetooth SIG, Inc.

Java, JME and all other Java-based marks are trademarks or registered trademarks of Sun Microsystems, Inc. in the United States and other countries.

The prediction engine of the input method is TOUCHPAL, provided by COOTEK.

DataViz and RoadSync are registered trademarks of DataViz, Inc. All rights reserved.

DataViz and Documents To Go are trademarks or registered trademarks of DataViz, Inc. All rights reserved.

Word To Go™, Sheet To Go®, Slideshow To Go®, PDF To Go® and icons are trademarks or registered trademarks of DataViz, Inc. All rights reserved.

SAR Information

THIS MOBILE DEVICE MEETS GUIDELINES FOR EXPOSURE TO RADIO WAVES. Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.

The exposure guidelines for mobile devices employ a unit of measurement known as the Specific Absorption Rate or SAR. The SAR limit stated in the ICNIRP guidelines is 2.0 W/kg averaged over 10 grams of tissue. Test for body worn SAR, the positions of the device are at a minimum of 1.5 cm from the body, with the device transmitting at its highest certified power level in all tested frequency bands. The actual SAR level of an operating device can be below the maximum value because the device is designed to use only the power required to reach the network. That amount changes depending on a number of factors such as how close you are to a network base station. The highest SAR value under the ICNIRP guidelines for use of the device at the body is

0.43 W/kg. Use of device accessories and enhancements may result in different SAR values. SAR values may vary depending on national reporting and testing requirements and the network band.

European Union Regulatory Conformance

The equipment complies with the RF Exposure Requirement 1999/519/EC, Council Recommendation of 12 July 1999 on the limitation of exposure of the general public to electromagnetic fields (0–300 GHz). This equipment meets the following conformance standards: EN50360, EN62311, EN60950-1, IEC60950-1, EN50332-1/2, EN301489-1, EN301489-3, EN301489-7, EN301489-17, EN301489-24, EN301511, EN301908-1/2, EN300328, EN300440-1/2, EN55022, EN55024.

For the device which tests accordance to EN60950-1:2006, it is mandatory to perform audio tests for EN50332. This device have been tested to comply with the Sound Pressure Level requirement laid down in the applicable EN 50332-1 and EN 50332-2 standards. Permanent hearing loss may occur if earphones or headphones are used at high volume for prolonged periods of time.



A pleine puissance, l'écoute prolongée du baladeur peut endommager l'oreille de l'utilisateur.

The conformity assessment procedure has been followed with the involvement of the following Notified Body:

PHOENIX TESTLAB

Identification mark: CE0700 (Notified Body) CE

CE 0700 !

Changes or modifications to this product not authorized by the manufacturer could void the EMC compliance and negate your authority to operate the product. This product has demonstrated EMC compliance under conditions that included the use of compliant peripheral devices and shielded cables between system components. It is important that you use compliant peripheral devices and shielded cables between system components to reduce the possibility of causing interference to radios, televisions, and other electronic devices.

Quick Start Guide

We, hereby, declare that this cellular, Wi-Fi, & Bluetooth radio is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Intellectual Property Right Information

Right to all technologies and products that comprise this device are the property of their respective owners:

This product has an Android platform based on Linux, which can be expanded by a variety of Java-Script-based application SW. Google, the Google logo, Android, the Android logo, Gmail, and YouTube are trademarks of Google Inc.

Bluetooth and the Bluetooth logo are trademarks owned by Bluetooth SIG, Inc.

Java, JME and all other Java-based marks are trademarks or registered trademarks of Sun Microsystems, Inc. in the United States and other countries.

microSD is a trademark of SD Card Association.

The prediction engine of the input method is TOUCHPAL, provided by COOTEK.

This equipment may be operated in:							
AT	BE	BG	CH	CY	CZ	DE	DK
EE	ES	FI	FR	GB	GR	HU	IE
IT	IS	LI	LT	LU	LV	MT	NL
NO	PL	PT	RO	SE	SI	SK	TR

Products with 2.4-GHz Wireless LAN Devices France

For 2.4-GHz wireless LAN operation of this product, certain restrictions apply. This equipment may use the entire-2400-MHz to 2483.5-MHz frequency band (channels 1 through 13) for indoor applications. For outdoor use, only 2400-2454 MHz frequency band (channels 1-9) may be used. For the latest requirements, see <http://www.art-telecom.fr>.



Camangi Corporation

For more information please visit <http://www.camangi.com>

Contact us: FM600_support@camangi.com

Power by Camangi ©2009-2010 Reserved by Camangi Corporation.

This document contained herein is the exclusive property of Camangi Corporation. and shall not be distributed, reproduced, or disclosed in whole or in part without prior written permission of Camangi Corporation