


## Exploded view



## Spare parts list

No.	Part Name	No.	Part Name
8	Electric motor	32	Circuit board
12	Switch	48	Filter (spare part)
19	Potentiometer	59	Joint tube